

Thank you for purchasing this item of furniture from One-Call.

Please find below some guide lines and safety information regarding your product.

WARNING

For safety purposes and to improve the appearance of the furniture item we strongly recommend that you remove the castors.

To remove castors on wardrobes and chests, insert a flathead screwdriver between the castor and the plastic floor guard and then pop out the wheel.

- Do not remove the floor guards as they protect the floor from the marking.



FOR YOUR OWN SAFETY, WE WOULD ALWAYS ADVISE THAT THE ITEM IS SECURED TO THE WALL USING WALL BRACKETS (NOT SUPPLIED).

Our furniture is equipped with 4D multi-directional, fully adjustable clip-on hinges.

To alter the position of any door, simply turn the relevant screw to the right or left as shown, using a cross-head screwdriver.

